

LIQUID ICE / LIQUID ICE EXTRA CUT



Liquid Ice... one polish, three pads.

Remove scratches with a single polish. Rather than changing compounds and pads to achieve a high gloss finish, you only need to change the pad. Liquid Ice polish matches the cut of the pad to the work.

FEATURES	BENEFITS
■ Simple	■ One product does it all
■ Versatile	■ Works on all types of paint finishes
■ Easy to use	■ Just squirt it on and buff it off
■ Multiple pads	■ For aggressive cut, intermediate polishing and fine finishing
■ One polish, three pads	■ No cross contamination
■ No swirl marks	■ Incredible high gloss
■ Water soluble	■ Easy to work with and clean up

Liquid Ice Polishing System



Remove scratches with a single polish. Rather than changing polish and pads to achieve a luster finish, you only change pads. Liquid Ice compound matches the cut of the pad to the work. Remove imperfections effortlessly for a quality job with a finish that glisters.

	BOTTLES	PADS	CLOTH	PACKAGE	PKG/CASE
DESCRIPTION	636425-	636425-	636425-		
Liquid Ice – Extra Cut – Quart	97116	–	–	1	4 new!
Liquid Ice – Quart	42075	–	–	1	4
Liquid Ice – Gallon	42076	–	–	1	2
Clean-up/Detailer Spray 32 oz.	42082	–	–	1	4
Micro-Fiber Wipe	–	–	04402	5	4
Clay Overspray Remover 100 gr.	42083	–	–	2 bars	4
8" Super Cut Wool Pad – Step 1	–	42077	–	1	6
9" Blue Cutting Foam Pad – Step 2	–	42078	–	1	6
9" White Finishing Foam Pad – Step 3	–	42079	–	1	6
Speed-Grip Back-Up Pad	–	42080	–	1	3
Alternate Pad for Step 1:					
8" x 3/4" nap Lambs Wool Pad	–	04703	–	–	12
8" Interface Pad (use with 04703)	–	04704	–	2	12



1

Use the Super Cut Wool Pad #42077. (Spur wool pad before starting to condition and remove loose yarns or dry polish). Apply Liquid Ice or Liquid Ice Extra Cut to the work area. To prevent slinging, spread over the work area with the polishing pad before starting machine. Buff (with pad slightly on edge) using medium pressure at 1000-1200 rpm. Remove all sand scratches with the wool pad before moving to pad #2.



2

Use the Blue Cutting Foam Pad #42078 and repeat step 1 except turn the buffer rpm up to 1500. Remove all polish swirl marks before moving to pad #3.



3

On dark finishes the White Finishing Foam Pad #42079 is recommended to remove the finest polish swirl marks and produce a high gloss finish (Buff at 1500 rpm).

NORTON